

620 - Diamond Flex-Lok™

Diamond Flex-Lok™ is a high-performance modular matting system that combines the durability and toughness of an industrial mat with true ergonomic support and comfort. The ergonomic properties of Diamond Flex-Lok are the result of a multi-tiered footing design that elevates the mat off the floor, creating air pockets that allow the mat to flex with the weight of the worker. A large hole drainage system facilitates the removal of liquids and debris from the work area while a pronounced raised diamond pattern on the mat surface, and an inverted-V pattern on the ramps provide additional traction.

Diamond Flex-Lok is manufactured from 100% recycled PVC for greater resistance to industrial chemicals, cutting fluids, oils and greases. A unique interlock system that comes apart only when you want it to allows for easy reconfiguration. Create your own workstation configuration or select an assembled stock size.

- PVC drainage modular interlocking tile with raised diamond top surface for traction and greater resistance to industrial chemicals
- Ergonomic, multi-tiered design elevates the mat from the floor, allowing liquid to continuously flow underneath the mat and lets the underside breathe
- Spring-back design is engineered to cushion the impact of long-term standing, allowing the mat to flex with the weight of the worker
- Black tiles & ramps made from 100% recycled PVC
- Stock size mats have beveled edges permanently affixed on 3 sides



WARNING: This product can expose you to chemicals including di-2-ethylhexyl phthalate and/or diisononyl phthalate which is known to the State of California to cause cancer, birth defects or reproductive harm. For more information, visit www.P65Warnings.ca.gov



Applications

- Workstations
- Food Prep Area
- Bar Areas
- Assembly Lines



Specifications

Sizes	12"x12" tiles, 6"x12" ramps, 6"x6" corners			
Assembled Stock Sizes	30"x36", 30"x48", 30"x60", 30"x72", 30"x96", 42"x72", 42"x96", 42"x120"			
Thickness	1"			
Colors	Assembled Black/Yellow Black	Tiles Black	Ramps/Corners Black Yellow	

NoTrax®

5655 West 73rd Street
Chicago, IL 60638

Phone: (800) 621-2802 **Fax:** (800) 322-7105

Email: customerservice@notrax.com

NoTrax.com